




Installation and operation manual

VRV system air conditioner



FXSA15A2VEB
FXSA20A2VEB
FXSA25A2VEB
FXSA32A2VEB
FXSA40A2VEB
FXSA50A2VEB
FXSA63A2VEB
FXSA80A2VEB
FXSA100A2VEB
FXSA125A2VEB
FXSA140A2VEB

Installation and operation manual
VRV system air conditioner

English

CE - DECLARATION-OF-CONFORMITY
CE - KONFORMITÄTSERKLÄRUNG
CE - DECLARATION-OF-CONFORMITE
CE - CONFORMITEITSVERKLARING
CE - DECLARACION-DE-CONFORMIDAD
CE - DICHIARAZIONE-DI-CONFORMITA
CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ

CE - DECLARAÇÃO-DE-CONFORMIDADE
CE - ЗАЯВЛЕНИЕ-О-СООТВЕТСТВИИ
CE - ÖVERENSSTÄMMELSEERKLÄRING
CE - FÖRSÄKRAN-OM-ÖVERENSSTÄMMELSE

CE - ERKLÆRING OM-SAMSVAR
CE - ILMOITUS-YHDENMUKAISUUDESTA
CE - PROHLÁŠENÍ-O-SHODĚ

CE - IZJAVA-O-USKLAĐENOSTI
CE - MEGFELELŐSÉGI-NYILATKOZAT
CE - DEKLARACIJA-ZGODNOSTI
CE - DECLARATIE-DE-CONFORMITATE

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARATSIOON
CE - ДЕКЛАРАЦИЯ-ЗА СЪОТВЕТСТВИЕ

CE - ATITIKTIES-DEKLARĀCIJA
CE - ATBILSTĪBAS-DEKLARĀCIJA
CE - VYHLÁŠENIE-ZHODY
CE - UYGUNLUK-BEYANI

Daikin Industries Czech Republic s.r.o.

01 declares under its responsibility that the conditions mentioned to which this declaration relates:
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836

[illegible][illegible]

FXSA15A2VEB, FXSA20A2VEB, FXSA25A2VEB, FXSA32A2VEB, FXSA40A2VEB, FXSA50A2VEB, FXSA63A2VEB, FXSA80A2VEB, FXSA100A2VEB, FXSA125A2VEB, FXSA140A2VEB,

are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:
 de volgende Norm(en) (of eenen anderen Normdocument (of -documenten) en/of andere Normdocument(s)), indien zij worden gebruikt overeenkomstig onze
 instructies:
 nos instructions:
 les normes (ou autres documents) normatifs, pour autant qu'ils soient utilisés conformément à nos instructions.

05 están en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras instrucciones:

066 sono conformi agli) seguente(i) standard(s) e/o altri(i) documento(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni
067 είναι σύμφωνα με τα(α) ακόλουθα(α) πρότυπα(α) ή άλλα έγγραφα(α) κανονισμών, υπό την προϋπόθεση ότι χρησιμοποιούνται σύμφωνα με τις οδηγίες μας:

EN60335-2-40,

11	following the provisions of:	10	under lagtgjælds af bestemmelserne i:
12	gemäß den Vorschriften der:	11	enligt vilkårene i:
13	conformément aux dispositions des:	12	gitt i henhold til bestemmelserne i:
14	conformemente ai regolamenti van:	13	konstatiran bestræmmelser:
15	siguiendo las disposiciones de:	14	za poornu ustanovno prepisui:
16	secondo le disposizioni per:	15	norma određena:
17	conformi alle disposizioni per:	16	podle ustanovljenih pravila:
18	acordo com o disposto em:	17	zgodnje s predpisovanjimi določbami:
19	conformi a disposições:	18	u skladu s odredbama izvan: dokaz:
20	conformi a disposições:	19	de uostrejšnjim dobbo:
21	conformément aux dispositions de:	20	vesjarinu nošetie:
22	conformemente ai regolamenti van:	21	crepaznu uslugu na:
23	siguiendo las disposiciones de:	22	lakants nuštas, patekamu:
24	secondo le disposizioni per:	23	ierotie prastus, nas notekas:
25	conformi alle disposizioni per:	24	darzadz uslaudušana:
26	acordo com o disposto em:	25	binu kuguama vgu darak:

01 Note	as set out in <A> and judged positively by according to the Certificate <C>	06 Nota	delineato nel <A> e giudicato positivamente da secondo il Certificato <C>	11 Information
02 Hinweis	wie in <A> angegeben und von positiv beurteilt gemäss Zertifikat <C>	07 Dujawont	amlyk kazykajzta tam <A> xam karyntnyk wstak, amlyk to ujawunje na <C> prastyntnyk <C>	12 Merk
03 Renarque	tel que défini dans <A> et évalué positivement par sur 08 Nota	08 Nota	de com estelesteado em <A> e com o parecer positivo de de acordo com o Certificado <C>	13 Huom
04 Bemerk	zawsze wymienię in <A> in positif beoordeeld door 09 Priimechanie	09 Priimechanie	ka kazykajzta <A> i xam soestawstajny s pomykajnymy reshenijem ssozdao <C> Gardezhewu <C>	14 Pomietka
05 Nota	positiv bemerkt <C> als vorgeordnetes Urteil	10 Bemerk	amlyk kazykajzta <A> positif urduetel af <C> l'entroid <C> Certificat <C>	15 Napomena

01** DIC***** is authorised to compile the Technica Construction File.
02** DIC***** hat die Berechtigung die Technische Konstruktionsakte zusammenzustellen.
03** DIC***** est autorisé à compiler le Dossier de Construction Technique.
04** DIC***** is bevoegd om het Technisch Constructiedossier samen te stellen.
05** DIC***** está autorizado a compilar el Archivo de Construcción Técnica.
06** DIC***** è autorizzata a redigere il File Tecnico di Costruzione.

07	Н ДСГ*** είναι εξουσιοδοτημένη να συντάξει τον Τεχνικό φάκελο κατασκευής.
08	Α ΔСГ*** esta autorizada a compilar el documento técnico de fabrico.
09	Компания ДСГ*** уполномочена составлять Комплект технической документации.
10	ДСГГ*** er autoriseret til at udarbejde de tekniske konstruktionsdata.
11	ДСГГ*** er beføjede til at sammenstille den tekniske konstruktionsfilen.
12	ДСГГ*** har tillatelse til at sammenstille den Tekniske konstruktionsfilen.

13^o DIC²⁰⁰⁰ on valitud teatavaa Teknisen asistajan.
14^o Společnost DIC²⁰⁰⁰ má oprávnění ke kompilaci souborů.
15^o DIC²⁰⁰⁰ je ověřen za Izradu Datoeake o termínový kol.
16^o ADIC²⁰⁰⁰ jogsut a mizsaki konstrukciós dokument.
17^o DIC²⁰⁰⁰ má upovázenie do zbierania i opracowywania
18^o DIC²⁰⁰⁰ este autorizat să compileze Dosarul Tehnic d

[illegible]

19⁹⁹ DiC²⁰⁰⁰ je poblaščen za sestavo datoteke s tehnično mapo.
20⁰⁰ DiC²⁰⁰⁰ on volituu kooelmaa tehnišu dokumentašoni.
21⁰¹ DiC²⁰⁰⁰ e otprizipana ba dštravni Arta za tehnišoa konstruksija.
22⁰² DiC²⁰⁰⁰ yra galioia sudaryti s tehnišes konstruksijos "laia".
23⁰³ DiC²⁰⁰⁰ ir autorizats sašadiati tehniško dokumentašoni.
24⁰⁴ Spobobn²⁰⁰⁵ DiC²⁰⁰⁰ je opraviena vyhoriti šibor tehniškie konstrukcie.
25⁰⁵ DiC²⁰⁰⁰ Tenik "Yapi Dersayman derelmeve vetikilur.

***DICz = Daikin Industries Czech Republic s.r.o.

Electromagnetic Compatibility 2014/30/EU
Machinery 2006/42/EC

11 Information*	enigi <A> polj gorkanis <A> enigi Certificati <A>	16 Neopjuzys
12 Merk*	soni dei ferikomer <A> gjenom positiv bedimelme <A> folje Certificat <A>	17 Uwaga*
13 Ruom*	polja on eseleni asialj pass <A> polja <A> on tyksylstj, Certificat <A> mikaseleni	18 Nota*
14 Poznani*	jak bio ujedeno <A> pozitivni zjstero <A> v soudaji <A> osviedcenj <A>	19 Opomba*
15 Napomena*	kako je izjsteno <A> pozitivno ocjlenjeno di strane je preima Certificati <A>	20 Markus*

07 H DIC^{***} «iva εμπορευμάτων συντάξη του Τυπικού φύλλου καταχώρισης»
08 A DIC^{***} «est autorizata a compila a documentație tehnica de fabrica»
09 C DIC^{***} «compilația este autorizată să compună documentația tehnică»
10 DIC^{***} «autoriseret fi utvæjdet af tekniske konstruktionstale»
11 DIC^{***} «ar bemyndiges att sammanställa den tekniska konstruktionssifflen»
12 DIC^{***} «har tillatelse til at kompilere den tekniske konstruktionssifflen»

13** DICz*** on vallalettu laamaan tekisen asiak
14** Společnost DICz*** ma oprávněni ke kompilaci
15** DICz*** je ovlašten za izradu Datobke o tehnick
16** A DICz*** josovti a mĩszaki konstrukciós dokum
17** DICz*** ma upovaznenie do zbierania i opracov
18** DICz*** este autorizat să compileze Dosarul tehni

konvultivnu laćman. Taksoni aspidok
svo DCL*** na opremljeni te kompleksi slobodni konstrukcije.
19** DCL*** je poluklasen
20** DCL*** on volatid kose
21** DCL*** i oroponata
22** DCL*** "va glazbi zbir"
23** DCL*** "je aralozis saša"
24** DCL*** je aralozis saša
25** Spodobost DCL*** je op
DCL*** Tenik Yapi Doc

19⁹⁹ DiC²⁰⁰⁰ je poblaščen za sestavo datoteke s tehnično mapo.
20⁰⁰ DiC²⁰⁰⁰ on volituu kooelmaa tehnišu dokumentašoni.
21⁰¹ DiC²⁰⁰⁰ e otprizipana ba dštravni Arta za tehnišoa konstruksija.
22⁰² DiC²⁰⁰⁰ yra galioia sudaryti s tehnišes konstruksijos "laia".
23⁰³ DiC²⁰⁰⁰ ir autorizats sašadiati tehniško dokumentašoni.
24⁰⁴ Spobobn²⁰⁰⁵ DiC²⁰⁰⁰ je opraviena vyhoriti šibor tehniškie konstrukcie.
25⁰⁵ DiC²⁰⁰⁰ Tenik "Yapi Dersayman derelmeve vetikilur.

***DICz = Daikin Industries Czech Republic s.r.o.

- 18 Diechtvor, az mendiantem respicivo
- 19 Diektiv, v smi spremenihi
- 20 Diektiv, ved frezga andrinar.
- 21 Diektiv, ved frezga andrinar.
- 22 Diektiv, ved frezga andrinar.
- 23 Diektiv, ved frezga andrinar.
- 24 Diektiv, ved frezga andrinar.
- 25 Diektiv, ved frezga andrinar.
- 26 Diektiv, ved frezga andrinar.
- 27 Diektiv, ved frezga andrinar.
- 28 Diektiv, ved frezga andrinar.
- 29 Diektiv, ved frezga andrinar.
- 30 Diektiv, ved frezga andrinar.
- 31 Diektiv, ved frezga andrinar.
- 32 Diektiv, ved frezga andrinar.
- 33 Diektiv, ved frezga andrinar.
- 34 Diektiv, ved frezga andrinar.
- 35 Diektiv, ved frezga andrinar.
- 36 Diektiv, ved frezga andrinar.
- 37 Diektiv, ved frezga andrinar.
- 38 Diektiv, ved frezga andrinar.
- 39 Diektiv, ved frezga andrinar.
- 40 Diektiv, ved frezga andrinar.
- 41 Diektiv, ved frezga andrinar.
- 42 Diektiv, ved frezga andrinar.
- 43 Diektiv, ved frezga andrinar.
- 44 Diektiv, ved frezga andrinar.
- 45 Diektiv, ved frezga andrinar.
- 46 Diektiv, ved frezga andrinar.
- 47 Diektiv, ved frezga andrinar.
- 48 Diektiv, ved frezga andrinar.
- 49 Diektiv, ved frezga andrinar.
- 50 Diektiv, ved frezga andrinar.
- 51 Diektiv, ved frezga andrinar.
- 52 Diektiv, ved frezga andrinar.
- 53 Diektiv, ved frezga andrinar.
- 54 Diektiv, ved frezga andrinar.
- 55 Diektiv, ved frezga andrinar.
- 56 Diektiv, ved frezga andrinar.
- 57 Diektiv, ved frezga andrinar.
- 58 Diektiv, ved frezga andrinar.
- 59 Diektiv, ved frezga andrinar.
- 60 Diektiv, ved frezga andrinar.
- 61 Diektiv, ved frezga andrinar.
- 62 Diektiv, ved frezga andrinar.
- 63 Diektiv, ved frezga andrinar.
- 64 Diektiv, ved frezga andrinar.
- 65 Diektiv, ved frezga andrinar.
- 66 Diektiv, ved frezga andrinar.
- 67 Diektiv, ved frezga andrinar.
- 68 Diektiv, ved frezga andrinar.
- 69 Diektiv, ved frezga andrinar.
- 70 Diektiv, ved frezga andrinar.
- 71 Diektiv, ved frezga andrinar.
- 72 Diektiv, ved frezga andrinar.
- 73 Diektiv, ved frezga andrinar.
- 74 Diektiv, ved frezga andrinar.
- 75 Diektiv, ved frezga andrinar.
- 76 Diektiv, ved frezga andrinar.
- 77 Diektiv, ved frezga andrinar.
- 78 Diektiv, ved frezga andrinar.
- 79 Diektiv, ved frezga andrinar.
- 80 Diektiv, ved frezga andrinar.
- 81 Diektiv, ved frezga andrinar.
- 82 Diektiv, ved frezga andrinar.
- 83 Diektiv, ved frezga andrinar.
- 84 Diektiv, ved frezga andrinar.
- 85 Diektiv, ved frezga andrinar.
- 86 Diektiv, ved frezga andrinar.
- 87 Diektiv, ved frezga andrinar.
- 88 Diektiv, ved frezga andrinar.
- 89 Diektiv, ved frezga andrinar.
- 90 Diektiv, ved frezga andrinar.
- 91 Diektiv, ved frezga andrinar.
- 92 Diektiv, ved frezga andrinar.
- 93 Diektiv, ved frezga andrinar.
- 94 Diektiv, ved frezga andrinar.
- 95 Diektiv, ved frezga andrinar.
- 96 Diektiv, ved frezga andrinar.
- 97 Diektiv, ved frezga andrinar.
- 98 Diektiv, ved frezga andrinar.
- 99 Diektiv, ved frezga andrinar.
- 100 Diektiv, ved frezga andrinar.

[illegible][illegible]

19⁹⁹ DiC²⁰⁰⁰ je poblaščen za sestavo datoteke s tehnično mapo.
20⁰⁰ DiC²⁰⁰⁰ on volituu kooelmaa tehnišu dokumentašoni.
21⁰¹ DiC²⁰⁰⁰ e otprizipana ba dštravni Arta za tehnišoa konstruksija.
22⁰² DiC²⁰⁰⁰ yra galioia sudaryti s tehnišes konstruksijos "laia".
23⁰³ DiC²⁰⁰⁰ ir autorizats sašadiati tehniško dokumentašoni.
24⁰⁴ Spobobn²⁰⁰⁵ DiC²⁰⁰⁰ je opraviena vyhoriti šibor tehniškie konstrukcie.
25⁰⁵ DiC²⁰⁰⁰ Tenik "Yapi Dersayman derelmeve vetikilur.

***DICz = Daikin Industries Czech Republic s.r.o.



DAIKIN INDUSTRIES CZECH REPUBLIC S.R.O.

U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany,

Czech Republic

3P480520-18E

Table of contents

1 About the documentation	3
1.1 About this document.....	3
2 Specific installer safety instructions	3
For the user	5
3 User safety instructions	5
3.1 General.....	5
3.2 Instructions for safe operation	5
4 About the system	7
4.1 System layout.....	8
5 User interface	8
6 Operation	8
6.1 Operation range	8
6.2 About operation modes	8
6.2.1 Basic operation modes	8
6.2.2 Special heating operation modes.....	9
6.3 To operate the system.....	9
7 Maintenance and service	9
7.1 Precautions for maintenance and service	9
7.2 Cleaning the air filter and air outlet.....	9
7.2.1 To clean the air filter	9
7.2.2 To clean the air outlet	10
7.3 About the refrigerant.....	10
7.3.1 About the refrigerant leakage sensor.....	10
8 Troubleshooting	11
9 Relocation	11
10 Disposal	11
For the installer	11
11 About the box	11
11.1 Indoor unit	11
11.1.1 To remove the accessories from the indoor unit.....	11
12 Unit installation	11
12.1 Preparing the installation site	11
12.1.1 Installation site requirements of the indoor unit	12
12.2 Mounting the indoor unit.....	12
12.2.1 Guidelines when installing the indoor unit.....	12
12.2.2 Guidelines when installing the ducting.....	13
12.2.3 Guidelines when installing the drain piping.....	14
13 Piping installation	16
13.1 Preparing refrigerant piping	16
13.1.1 Refrigerant piping requirements.....	16
13.1.2 Refrigerant piping insulation	16
13.2 Connecting the refrigerant piping	16
13.2.1 To connect the refrigerant piping to the indoor unit	16
14 Electrical installation	16
14.1 Specifications of standard wiring components	17
14.2 To connect the electrical wiring to the indoor unit	17
15 Commissioning	18
15.1 Checklist before commissioning	18
15.2 To perform a test run.....	18
16 Configuration	18

16.1 Field setting	18
17 Technical data	20
17.1 Wiring diagram	20
17.1.1 Unified wiring diagram legend.....	20

1 About the documentation

1.1 About this document



INFORMATION

Make sure that the user has the printed documentation and ask him/her to keep it for future reference.

Target audience

Authorised installers + end users



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.



WARNING

Make sure installation, servicing, maintenance, repair and applied materials follow the instructions from Daikin and, in addition, comply with applicable legislation and are performed by qualified persons only. In Europe and areas where IEC standards apply, EN/IEC 60335-2-40 is the applicable standard.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you must read before installing
 - Format: Paper (in the box of the indoor unit)
- **Indoor unit installation and operation manual:**
 - Installation and operation instructions
 - Format: Paper (in the box of the indoor unit)
- **Installer and user reference guide:**
 - Preparation of the installation, good practices, reference data,...
 - Detailed step-by-step instructions and background information for basic and advanced usage
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

2 Specific installer safety instructions

Always observe the following safety instructions and regulations.

2 Specific installer safety instructions

General



WARNING

Make sure installation, servicing, maintenance, repair and applied materials follow the instructions from Daikin and, in addition, comply with applicable legislation and are performed by qualified persons only. In Europe and areas where IEC standards apply, EN/IEC 60335-2-40 is the applicable standard.

Installation site (see "12.1 Preparing the installation site" ▶ 11)



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



CAUTION

Appliance not accessible to the general public, install it in a secured area, protected from easy access.

This unit, both indoor and outdoor, is suitable for installation in a commercial and light industrial environment.



CAUTION

The total refrigerant charge in the system cannot exceed the requirements for minimum floor area of the smallest room that is served. For minimum floor area requirements for indoor units, see the installation and operation manual of the outdoor unit.

Duct installation (see "12.2.2 Guidelines when installing the ducting" ▶ 13)



WARNING

Do NOT install operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in the duct work.



CAUTION

- Make sure the installation of the duct does NOT exceed the setting range of the external static pressure for the unit. Refer to the technical datasheet of your model for the setting range.
- Make sure to install the canvas duct so vibrations are NOT transmitted to the duct or ceiling. Use a sound-absorbing material (insulation material) for the lining of the duct and apply vibration insulation rubber to the hanging bolts.
- When welding, make sure NOT to spatter onto the drain pan or the air filter.
- If the metal duct passes through a metal lath, wire lath or metal plate of the wooden structure, separate the duct and wall electrically.
- Install the outlet grille in a position where the airflow will not come into direct contact with people.
- Do NOT use booster fans in the duct. Use the function to adjust the fan rate setting automatically (see "16.1 Field setting" ▶ 18).

Refrigerant piping installation (see "13 Piping installation" ▶ 16)



CAUTION

- Do NOT use mineral oil on flared part.
- Do NOT reuse piping from previous installations.
- NEVER install a drier to this R32 unit to guarantee its lifetime. The drying material may dissolve and damage the system.



CAUTION

- Incomplete flaring may cause refrigerant gas leakage.
- Do NOT re-use flares. Use new flares to prevent refrigerant gas leakage.
- Use flare nuts that are included with the unit. Using different flare nuts may cause refrigerant gas leakage.



CAUTION

Install the refrigerant piping or components in a position where they are unlikely to be exposed to any substance which may corrode components containing refrigerant, unless the components are constructed of materials that are inherently resistant to corrosion or are suitably protected against corrosion.



WARNING: MILDLY FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.

Electrical installation (see "14 Electrical installation" ▶ 16)



WARNING

- All wiring MUST be performed by an authorised electrician and MUST comply with the applicable legislation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction MUST comply with the applicable legislation.



WARNING

- If the power supply has a missing or wrong N-phase, equipment might break down.
- Establish proper earthing. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earthing may cause electrical shock.
- Install the required fuses or circuit breakers.
- Secure the electrical wiring with cable ties so that the cables do NOT come in contact with sharp edges or piping, particularly on the high-pressure side.
- Do NOT use taped wires, stranded conductor wires, extension cords, or connections from a star system. They can cause overheating, electrical shock or fire.
- Do NOT install a phase advancing capacitor, because this unit is equipped with an inverter. A phase advancing capacitor will reduce performance and may cause accidents.



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provide full disconnection under overvoltage category III.



WARNING

If the supply cord is damaged, it **MUST** be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



CAUTION

- Each indoor unit has to be connected to a separate user interface. Only a safety system compatible remote controller can be used as the user interface. See technical data sheet for remote controller compatibility (e.g. BRC1H52/82*).
- The user interface has to be put in the same room as the indoor unit. For details, please refer to the installation and operation manual of the user interface.

For the user

3 User safety instructions

Always observe the following safety instructions and regulations.

3.1 General



WARNING

If you are **NOT** sure how to operate the unit, contact your installer.



WARNING

This appliance is not intended for use by persons, including children, with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Cleaning and user maintenance must not be carried out by children without supervision.



WARNING

To prevent electrical shocks or fire:

- Do **NOT** rinse the unit.
- Do **NOT** operate the unit with wet hands.
- Do **NOT** place any objects containing water on the unit.



CAUTION

- Do **NOT** place any objects or equipment on top of the unit.

- Do **NOT** sit, climb or stand on the unit.

- Units are marked with the following symbol:



This means that electrical and electronic products may **NOT** be mixed with unsorted household waste. Do **NOT** try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and of other parts must be done by an authorized installer and must comply with applicable legislation.

Units must be treated at a specialized treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. For more information, contact your installer or local authority.

- Batteries are marked with the following symbol:



This means that the batteries may **NOT** be mixed with unsorted household waste. If a chemical symbol is printed beneath the symbol, this chemical symbol means that the battery contains a heavy metal above a certain concentration.

Possible chemical symbols are: Pb: lead (>0.004%).

Waste batteries must be treated at a specialized treatment facility for reuse. By ensuring waste batteries are disposed of correctly, you will help to prevent potential negative consequences for the environment and human health.

3.2 Instructions for safe operation



WARNING

- Do not modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electric shock or fire. Contact your dealer.

3 User safety instructions

- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and mildly flammable, but it will generate toxic gas when it accidentally leaks into a room where combustible air from fan heaters, gas cookers, etc. is present. Always have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.

CAUTION

This unit is equipped with electrically powered safety measures, such as a refrigerant leak detector. In order to be effective, the unit must be electrically powered at all times after installation, except for short service periods.

CAUTION

- NEVER touch the internal parts of the controller.
- Do NOT remove the front panel. Some parts inside are dangerous to touch and appliance problems may happen. For checking and adjusting the internal parts, contact your dealer.

WARNING

This unit contains electrical and hot parts.

WARNING

Before operating the unit, be sure the installation has been carried out correctly by an installer.

CAUTION

It is not good for your health to expose your body to the air flow for a long time.

CAUTION

To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the system.

CAUTION

Do NOT operate the system when using a room fumigation-type insecticide. Chemicals could collect in the unit, and endanger the health of people who are hypersensitive to chemicals.

CAUTION

NEVER expose little children, plants or animals directly to the airflow.

WARNING

Do NOT place objects below the indoor and/or outdoor unit that may get wet. Otherwise condensation on the unit or refrigerant pipes, air filter dirt or drain blockage may cause dripping, and objects under the unit may get dirty or damaged.

WARNING

Do NOT place a flammable spray bottle near the air conditioner and do NOT use sprays near the unit. Doing so may result in a fire.

Maintenance and service (see "[7 Maintenance and service](#)" )

CAUTION: Pay attention to the fan!

It is dangerous to inspect the unit while the fan is running.

Be sure to turn off the main switch before executing any maintenance task.

CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.

WARNING

Never replace a fuse with a fuse of a wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.

**CAUTION**

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.

**CAUTION**

Before accessing terminal devices, make sure to interrupt all power supply.

**DANGER: RISK OF ELECTROCUTION**

To clean the air conditioner or air filter, be sure to stop operation and turn all power supplies off. Otherwise, an electric shock and injury may result.

**WARNING**

Be careful with ladders when working in high places.

**CAUTION**

Turn off the unit before cleaning the air filter and air outlet.

**WARNING**

Do NOT let the indoor unit get wet.
Possible consequence: Electric shock or fire.

About the refrigerant (see "7.3 About the refrigerant" ▶ 10))

**WARNING: MILDLY FLAMMABLE MATERIAL**

The refrigerant inside this unit is mildly flammable.

**WARNING**

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.

**WARNING**

The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a

burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.

Turn off any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.

Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.

**WARNING**

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).

**WARNING**

It is necessary to replace the sensor after every detection or at the end of the lifetime. Authorized person only **MUST** replace the sensor.

Troubleshooting (see "8 Troubleshooting" ▶ 11))

**WARNING**

Stop operation and shut off the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electric shock or fire. Contact your dealer.

4 About the system

**WARNING**

- Do not modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electric shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and mildly flammable, but it will generate toxic gas when it accidentally leaks into a room where combustible air from fan heaters, gas cookers, etc. is present. Always have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.

5 User interface



NOTICE

Do NOT use the system for other purposes. In order to avoid any quality deterioration, do NOT use the unit for cooling precision instruments, food, plants, animals, or works of art.



NOTICE

For future modifications or expansions of your system:

A full overview of allowable combinations (for future system extensions) is available in technical engineering data and should be consulted. Contact your installer to receive more information and professional advice.



CAUTION


This unit is equipped with electrically powered safety measures, such as a refrigerant leak detector. In order to be effective, the unit must be electrically powered at all times after installation, except for short service periods.

4.1 System layout



INFORMATION

The following illustration is an example and might NOT match your system layout.



- a Indoor unit
- b Outdoor unit
- c User interface
- d Suction air
- e Discharge air
- f Refrigerant piping + transmission cable
- g Drain pipe

5 User interface



CAUTION

- NEVER touch the internal parts of the controller.
- Do NOT remove the front panel. Some parts inside are dangerous to touch and appliance problems may happen. For checking and adjusting the internal parts, contact your dealer.



NOTICE

Do NOT wipe the controller operation panel with benzene, thinner, chemical dust cloth, etc. The panel may get discoloured or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. Wipe it with another dry cloth.



NOTICE

NEVER press the button of the user interface with a hard, pointed object. The user interface may be damaged.



NOTICE

NEVER pull or twist the electric wire of the user interface. It may cause the unit to malfunction.

This operation manual offers a non-exhaustive overview of the main functions of the system.

For more information about the user interface, see the operation manual of the installed user interface.

6 Operation

6.1 Operation range



INFORMATION

For the operation limits see the technical data of the connected outdoor unit.

6.2 About operation modes



INFORMATION

Depending on the installed system, some operation modes will not be available.

- The air flow rate may adjust itself depending on the room temperature or the fan may stop immediately. This is not a malfunction.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.
- **Setpoint.** Target temperature for the Cooling, Heating, and Auto operation modes.
- **Setback.** A function that keeps the room temperature in a specific range when the system is turned off (by the user, the schedule function, or the OFF timer).

6.2.1 Basic operation modes

The indoor unit can operate in various operation modes.

Icon	Operation mode
	Cooling. In this mode, cooling will be activated as required by the setpoint, or by Setback operation.
	Heating. In this mode, heating will be activated as required by the setpoint, or by Setback operation.
	Fan only. In this mode, air circulates without heating or cooling.
	Auto. In Auto mode, the indoor unit automatically switches between heating and cooling mode, as required by the setpoint.

6.2.2 Special heating operation modes

Operation	Description
Defrost	To prevent a loss of heating capacity due to frost accumulation in the outdoor unit, the system will automatically switch to defrost operation. During defrost operation, the indoor unit fan will stop operation, and the following icon will appear on the home screen:  The system will resume normal operation after approximately 6 to 8 minutes.
Hot start	During hot start, the indoor unit fan will stop operation, and the following icon will appear on the home screen: 

6.3 To operate the system



INFORMATION

For setting of the operation mode or other settings, see the reference guide or operation manual of the user interface.

7 Maintenance and service

7.1 Precautions for maintenance and service



NOTICE

Maintenance **MUST** be done by an authorized installer or service agent.

We recommend performing maintenance at least once a year. However, applicable legislation might require shorter maintenance intervals.



CAUTION

Do **NOT** insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.



NOTICE

Never inspect or service the unit by yourself. Ask a qualified service person to perform this work. However, as end user, you may clean the air filter and air outlet.



WARNING

Never replace a fuse with a fuse of a wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.



CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.



NOTICE

Do **NOT** wipe the controller operation panel with benzine, thinner, chemical dust cloth, etc. The panel may get discoloured or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. Wipe it with another dry cloth.



CAUTION

Before accessing terminal devices, make sure to interrupt all power supply.



DANGER: RISK OF ELECTROCUTION

To clean the air conditioner or air filter, be sure to stop operation and turn all power supplies off. Otherwise, an electric shock and injury may result.



WARNING

Be careful with ladders when working in high places.

Following symbols may occur on the indoor unit:

Symbol	Explanation
	Measure the voltage at the terminals of main circuit capacitors or electrical components before servicing.

7.2 Cleaning the air filter and air outlet



CAUTION

Turn off the unit before cleaning the air filter and air outlet.

7.2.1 To clean the air filter

When to clean the air filter:

- Rule of thumb: Clean every 6 months. If the air in the room is extremely contaminated, increase the cleaning frequency.
- Depending on the settings, the user interface can display the "Time to clean filter" notification. Clean the air filter when the notification is displayed.
- If the dirt becomes impossible to clean, change the air filter (= optional equipment).


How to clean the air filter:



NOTICE


Do **NOT** use water of 50°C or higher. **Possible consequence:** Discoloration and deformation.

- Remove the air filter.** Pull its cloth upward (in case of rear suction) or backward (in case of bottom suction).



- Clean the air filter.** Use a vacuum cleaner or wash with water. If the air filter is very dirty, use a soft brush and neutral detergent.

7 Maintenance and service




3 Dry the air filter in the shadow.

4 Re-attach the air filter. Align the 2 hanger brackets and push the 2 clips in their place and pull the cloth if necessary.

rear suction

bottom suction



5 Confirm that all hangers are fixed.

6 In case of bottom suction, close the air inlet grille. In case of rear suction, close service duct opening.

7 Turn ON the power.

8 To remove warning screens, see the reference guide of the user interface.

7.2.2 To clean the air outlet



WARNING

Do NOT let the indoor unit get wet. **Possible consequence:** Electric shock or fire.



NOTICE

- Do NOT use gasoline, benzene, thinner polishing powder or liquid insecticide. **Possible consequence:** Discoloration and deformation.
- Do NOT use water or air of 50°C or higher. **Possible consequence:** Discoloration and deformation.

Clean with a soft cloth. If it is difficult to remove stains, use water or a neutral detergent.

7.3 About the refrigerant

This product contains fluorinated greenhouse gases. Do NOT vent gases into the atmosphere.

Refrigerant type: R32

Global warming potential (GWP) value: 675



NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO₂ equivalent.

Formula to calculate the quantity in CO₂ equivalent tonnes: GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

Please contact your installer for more information.



WARNING: MILDLY FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.



WARNING

The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.

Turn off any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.

Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.

7.3.1 About the refrigerant leakage sensor



WARNING

It is necessary to replace the sensor after every detection or at the end of the lifetime. Authorized person only MUST replace the sensor.



NOTICE

Functionality of the safety measures are periodically automatically checked. In case of malfunction, error code will display on the user interface.



NOTICE

The R32 refrigerant leakage sensor is a semiconductor detector which may incorrectly detect substances other than R32 refrigerant. Avoid using chemical substances (e.g. organic solvents, hair spray, paint) in high concentrations, in the close proximity of the indoor unit because this may cause misdetection of the R32 refrigerant leakage sensor.



INFORMATION

Lifetime of the sensor is 10 years. The user interface displays error "**CH-05**" 6 months before the end of the sensor lifetime and error "**CH-02**" after the end of the sensor lifetime. For more information refer to the reference guide of the user interface and contact your dealer.

In case of detection when the unit is standby

When the detection occurs when the unit is standby, "false detection check" will occur.

False detection check

- Unit starts fan operation on the lowest setting.
 - User interface displays error code "**A0-13**", emits alarm sound and status indicator is blinking.
 - Sensor checks if refrigerant leakage or misdetection occurred.
- If refrigerant leakage is NOT detected, **Result:** system returns to normal operation after approximately 2 minutes.

- If refrigerant leakage is detected, **Result:**
 - 1 User interface displays error "A0-11", emits alarm sound and status indicator is blinking.
 - 2 Contact your dealer immediately. For more information, see the installation manual of the outdoor unit.

In case of detection when the unit is turned on

- 1 User interface displays error "A0-11", emits alarm sound and status indicator is blinking.
- 2 Contact your dealer immediately. For more information, see the installation manual of the outdoor unit.



INFORMATION

To stop alarm of the user interface see the reference guide of the user interface.



INFORMATION

The minimum airflow during normal operation or during the refrigerant leakage detection is always >240 m³/h.

8 Troubleshooting

If one of the following malfunctions occur, take the measures shown below and contact your dealer.



WARNING

Stop operation and shut off the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electric shock or fire. Contact your dealer.

The system **MUST** be repaired by a qualified service person.

Malfunction	Measure
If a safety device such as a fuse, a circuit breaker or a residual current device frequently actuates or the ON/OFF switch does NOT function properly.	Turn OFF all main power supply switches to the unit.

Malfunction	Measure
If water leaks from the unit.	Stop operation.
The operation switch does NOT function properly.	Turn OFF the power supply.
If the user interface displays	Notify your installer and report the error code. To display an error code see the reference guide of the user interface.

If the system does NOT operate properly except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system in accordance with the following procedures.



INFORMATION

Refer to the reference guide located on <http://www.daikineurope.com/support-and-manuals/product-information/> for more troubleshooting tips.

If after checking all above items, it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the unit (with manufacturing number if possible) and the installation date (possibly listed on the warranty card).

9 Relocation

Contact your dealer for removing and reinstalling the total unit. Moving units requires technical expertise.

10 Disposal



NOTICE


Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts **MUST** comply with applicable legislation. Units **MUST** be treated at a specialised treatment facility for reuse, recycling and recovery.

For the installer

11 About the box

11.1 Indoor unit

11.1.1 To remove the accessories from the indoor unit



- c Washers for hanger bracket
- d Screws for duct flanges
- e Metal clamp
- f Sealing pads: Large (drain pipe), medium 1 (gas pipe), medium 2 (liquid pipe)
- g Drain hose
- h Small sealing
- i Insulation piece: Small (liquid pipe)
- j Insulation piece: Large (gas pipe)
- k Tie wraps

12 Unit installation

12.1 Preparing the installation site

Avoid installation in an environment with a lot of organic solvents such as ink and siloxane.

12 Unit installation



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).


12.1.1 Installation site requirements of the indoor unit



INFORMATION

The sound pressure level is less than 70 dBA.

- **Spacing.** Mind the following requirements:




- A Minimum distance to the floor**
2.7 m to avoid accidental touching
2.5 m in case the fan is covered (e.g. false ceiling, grille, ...)
- a** Ceiling
- b** Floor surface
- c** Maintenance space

- **Discharge grille.** Minimum requirement installation height of discharge grille ≥ 1.8 m.


Service space and ceiling opening size

Make sure ceiling opening is big enough to ensure a sufficient clearance for maintenance and service.



- A** Side view: refrigerant piping, drain piping, control box
- B** Side view: air inlet
- C** Top view
- a** Ceiling opening
Class 15~32: 550 mm
Class 40~50: 700 mm
Class 63~80: 1000 mm
Class 100~125: 1400 mm
Class 140: 1550 mm
- b** Service space

Installation options



- A** Standard rear suction
- B** Installation with rear canvas duct and duct service opening
- C** Installation with bottom canvas duct and air inlet grill
- a** Ceiling surface
- b** Ceiling opening
- c** Air filter
- d** Air inlet duct
- e** Duct service opening
- f** Interchangeable plate
- g** Canvas connection for air inlet panel (field supply)
- h** Air inlet panel (field supply) opening



INFORMATION

Some options may require additional service space. Refer to the installation manual of the used option before installation.

Minimum floor area requirements



CAUTION

The total refrigerant charge in the system cannot exceed the requirements for minimum floor area of the smallest room that is served. For minimum floor area requirements for indoor units, see the installation and operation manual of the outdoor unit.

12.2 Mounting the indoor unit

12.2.1 Guidelines when installing the indoor unit



INFORMATION


Optional equipment. When installing optional equipment, also read the installation manual of the optional equipment. Depending on the field conditions, it might be easier to install the optional equipment first.

Installation options



INFORMATION


The unit can be used with bottom suction by replacing the interchangeable plate by the air filter holding plate.



a Air filter holding plate with air filter(s)
b Interchangeable plate


- **Ceiling strength.** Check whether the ceiling is strong enough to support the weight of the unit. If there is a risk, reinforce the ceiling before installing the unit.

- For existing ceilings, use anchors.
- For new ceilings, use sunken inserts, sunken anchors or other field supplied parts.



a Anchor
b Ceiling slab
c Long nut or turnbuckle
d Suspension bolt
e Indoor unit

- **Suspension bolts.** Use M10 suspension bolts for installation. Attach the hanger bracket to the suspension bolt. Fix it securely using a nut and washer from the upper and lower sides of the hanger bracket.




a Nut (field supply)
b Washer (accessories)
c Hanger bracket
d Double nut (field supply)
e Suspension bolt pitch

Class	A (mm)
15~32	588
40~50	738
63~80	1038
100~125	1438

Class	A (mm)
140	1588

- **Level.** Make sure the unit is level at all four corners using a level or a water-filled vinyl tube.



NOTICE

Do NOT install the unit tilted. **Possible consequence:** If the unit is tilted against the direction of the condensate flow (the drain piping side is raised), the float switch might malfunction and cause water to drip.

12.2.2 Guidelines when installing the ducting



WARNING

Do NOT install operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in the duct work.




CAUTION

- Make sure the installation of the duct does NOT exceed the setting range of the external static pressure for the unit. Refer to the technical datasheet of your model for the setting range.
- Make sure to install the canvas duct so vibrations are NOT transmitted to the duct or ceiling. Use a sound-absorbing material (insulation material) for the lining of the duct and apply vibration insulation rubber to the hanging bolts.
- When welding, make sure NOT to spatter onto the drain pan or the air filter.
- If the metal duct passes through a metal lath, wire lath or metal plate of the wooden structure, separate the duct and wall electrically.
- Install the outlet grille in a position where the airflow will not come into direct contact with people.
- Do NOT use booster fans in the duct. Use the function to adjust the fan rate setting automatically (see "16.1 Field setting" ▶ 18).

The ducting is to be field supplied.

- 1 Connect the canvas duct to the inside of the flange on both inlet and outlet side. For connecting the canvas duct, use accessory screws.
- 2 Connect the duct to the canvas duct.




a Screws for duct flanges (accessory)
b Flange (located on the unit)
c Indoor unit
d Insulation (field supply)

12 Unit installation

- e Canvas duct (field supply)
- f Aluminium tape (field supply)

- **Fixing screws.** When installing an air inlet duct, select fixing screws that stick out 5 mm on the inside of the flange to protect the air filter from damage during maintenance of the filter.



- a Air inlet duct
- b Inside of the flange
- c Fixing screw

- 3 Wind aluminium tape around the flange and duct connection. Make sure there are no air leaks at any other connection.
 - 4 Insulate the duct to prevent condensation from forming. Use glass wool or polyethylene foam 25 mm thick.
- **Filter.** Be sure to attach an air filter inside the air passage on the intake side. Use an air filter with dust collecting efficiency $\geq 50\%$ (gravimetric method).


12.2.3 Guidelines when installing the drain piping

Make sure condensation water can be evacuated properly. This involves:

- General guidelines
- Connecting the drain piping to the indoor unit
- Checking for water leaks


General guidelines

- **Pipe length.** Keep drain piping as short as possible.
- **Pipe size.** Keep the pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 20 mm nominal diameter and 26 mm outer diameter).
- **Slope.** Make sure the drain piping slopes down (at least 1/100) to prevent air from being trapped in the piping. Use hanging bars as shown.




- a Hanging bar
- O Allowed
- X Not allowed

- **Condensation.** Take measures against condensation. Insulate the complete drain piping in the building.
- **Rising piping.** If necessary to make the slope possible, you can install rising piping.
 - Drain hose inclination: 0~75 mm to avoid stress on the piping and to avoid air bubbles.



- a Metal clamp (accessory)
- b Drain hose (accessory)
- c Rising drain piping (vinyl pipe nominal Ø20 mm and outer Ø26 mm)
- d Hanging bars (field supply)

- **Combining drain pipes.** You can combine drain pipes. Make sure to use drain pipes and T-joints with the correct gauge for the operating capacity of the units.




- a T-joint

To connect the drain piping to the indoor unit




NOTICE

Incorrect connection of the drain hose might cause leaks, and damage the installation space and surroundings.



- a Drain outlet for maintenance
- b Refrigerant pipes
- c Drain pipe connection

- 1 Push the drain hose as far as possible over the drain pipe connection.
- 2 Tighten the metal clamp until the screw head is less than 4 mm from the metal clamp part.
- 3 Check for water leaks (see ["To check for water leaks"](#) [p 15]).
- 4 Wind the large sealing pad (= insulation) around the metal clamp and drain hose, and fix it with tie wraps.
- 5 Connect the drain piping to the drain hose.




- a Drain pipe connection (attached to the unit)
- b Drain hose (accessory)
- c Metal clamp (accessory)
- d Large sealing pad (accessory)
- e Drain piping (field supply)

NOTICE

- Do NOT remove the drain pipe plug. Water might leak out.
- Use the drain outlet only to discharge the water before maintenance.
- Insert and remove the drain plug gently. Excessive force may deform the drain socket of the drain pan.


Pull out the plug.

- Do NOT wiggle the plug up and down.



Push in the plug.

- Set the plug and push it in using a Phillips screwdriver.




- a Drain plug
- b Phillips screwdriver

To check for water leaks

The procedure differs depending on whether installation of the system is already completed. When installation of the system is not yet completed, temporarily connect the user interface and power supply to the unit.


When installation of the system is not yet completed

- 1 Temporarily connect electrical wiring.
 - Remove the service cover (c).
 - Connect the power supply (a).
 - Connect the user interface (b).
 - Reattach the service cover.



- a Power supply terminal block
- b User interface terminal block
- c Service cover with wiring diagram

- 2 Turn ON the power supply.
- 3 Start fan only operation (see the reference guide or the service manual of the user interface).
- 4 Remove the water inlet cover (1 screw).
- 5 Gradually pour approximately 1 l of water through the water inlet, and check for leaks.



- a Water inlet
- b Portable pump
- c Water inlet cover
- d Bucket (adding water through water inlet)
- e Drain outlet for maintenance
- f Refrigerant pipes

- 6 Turn OFF the power.
- 7 Disconnect the electrical wiring.
 - Remove the service cover.
 - Disconnect the power supply.
 - Disconnect the user interface.
 - Reattach the service cover.

When installation of the system is already completed

- 1 Start cooling operation (see the reference guide or the service manual of the user interface).
- 2 Gradually pour approximately 1 l of water through the water inlet, and check for leaks (see "When installation of the system is not yet completed" ▶ 15)).

13 Piping installation

13 Piping installation

13.1 Preparing refrigerant piping

13.1.1 Refrigerant piping requirements



CAUTION

Piping **MUST** be installed according to instructions given in "13 Piping installation" [▶ 16]. Only mechanical joints (e.g. braze+flare connections) that are compliant with the latest version of ISO14903 can be used.



NOTICE

The piping and other pressure-containing parts shall be suitable for refrigerant. Use phosphoric acid deoxidised seamless copper for refrigerant.

- Foreign materials inside pipes (including oils for fabrication) must be ≤30 mg/10 m.

Refrigerant piping diameter

For piping connections of the indoor unit use the following piping diameters:

Class	Pipe outer diameter (mm)	
	Liquid piping	Gas piping
15~32	Ø6.4 mm	Ø9.5 mm
40~80	Ø6.4 mm	Ø12.7 mm
100~140	Ø9.5 mm	Ø15.9 mm

Refrigerant piping material

- Piping material:** Phosphoric acid deoxidised seamless copper.
- Flare connections:** Only use annealed material.
- Piping temper grade and thickness:**

Outer diameter (Ø)	Temper grade	Thickness (t) ^(a)	
6.4 mm (1/4")	Annealed (O)	≥0.8 mm	
9.5 mm (3/8")			
12.7 mm (1/2")			
15.9 mm (5/8")			

^(a) Depending on the applicable legislation and the maximum working pressure of the unit (see "PS High" on the unit name plate), larger piping thickness might be required.

13.1.2 Refrigerant piping insulation

- Use polyethylene foam as insulation material:
 - with a heat transfer rate between 0.041 and 0.052 W/mK (0.035 and 0.045 kcal/mh°C)
 - with a heat resistance of at least 120°C
- Insulation thickness

Pipe outer diameter (Ø _p)	Insulation inner diameter (Ø _i)	Insulation thickness (t)
6.4 mm (1/4")	8~10 mm	≥10 mm
9.5 mm (3/8")	10~14 mm	≥13 mm
12.7 mm (1/2")	14~16 mm	≥13 mm
15.9 mm (5/8")	16~20 mm	≥13 mm



If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

13.2 Connecting the refrigerant piping



DANGER: RISK OF BURNING/SCALDING

13.2.1 To connect the refrigerant piping to the indoor unit



CAUTION


Install the refrigerant piping or components in a position where they are unlikely to be exposed to any substance which may corrode components containing refrigerant, unless the components are constructed of materials that are inherently resistant to corrosion or are suitably protected against corrosion.



WARNING: MILDLY FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.

- Pipe length.** Keep refrigerant piping as short as possible.
- Flare connections.** Connect refrigerant piping to the unit using flare connections.
- Insulation.** Insulate the refrigerant piping on the indoor unit as follows:



- A Gas piping
- B Liquid piping

- a Insulation material (field supply)
- b Tie wrap (accessory)
- c Insulation pieces: Large (gas pipe), small (liquid pipe) (accessories)
- d Flare nut (attached to the unit)
- e Refrigerant pipe connection (attached to the unit)
- f Unit
- g Sealing pads: Medium 1 (gas pipe), medium 2 (liquid pipe) (accessories)

- Turn up the seams of the insulation pieces.
- Attach to the base of the unit.
- Tighten the tie wrap on the insulation pieces.
- Wrap the sealing pad from the base of the unit to the top of the flare nut.



NOTICE

Make sure to insulate all refrigerant piping. Any exposed piping might cause condensation.

14 Electrical installation



DANGER: RISK OF ELECTROCUTION



WARNING

ALWAYS use multicore cable for power supply cables.


WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provide full disconnection under overvoltage category III.


WARNING

If the supply cord is damaged, it **MUST** be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

14.1 Specifications of standard wiring components

Component		
Power supply cable	MCA ^(a)	"14-1 Minimum circuit ampacity" [p. 17]
	Voltage	220~240 V
	Phase	1~
	Frequency	50/60 Hz
	Wire sizes	1.5 mm ² (3-core wire) H07RN-F (60245 IEC 66)
Transmission wiring	0.75 to 1.25 mm ² (2-core wire)	
User interface cable	H05RN-F (60245 IEC 57) User interface - maximum 500 m	
Recommended field fuse	6 A	
Residual current device	Must comply with applicable legislation	

^(a) MCA=Minimum circuit ampacity. Stated values are maximum values (see electrical data of indoor unit for exact values).

14-1 Minimum circuit ampacity

Class						
15~25	32	40~63	80	100	125	140
0.8 A	0.9 A	1.4 A	1.7 A	2 A	2.2 A	3 A

14.2 To connect the electrical wiring to the indoor unit


NOTICE

- Follow the wiring diagram (delivered with the unit, located at the inside of the service cover).
- For instructions on how to connect the optional equipment, see the installation manual delivered with the optional equipment.
- Make sure the electrical wiring does NOT obstruct proper reattachment of the service cover.

It is important to keep the power supply and the transmission wiring separated from each other. In order to avoid any electrical interference the distance between both wirings should ALWAYS be at least 50 mm.


NOTICE

Be sure to keep the power line and transmission line apart from each other. Transmission wiring and power supply wiring may cross, but may NOT run parallel.

- Remove the service cover.


- User interface cable:** Route the cable through the frame, connect the cable to the terminal block (symbols P1, P2) and fix the cable with a tie wrap.

- Transmission cable:** Route the cable through the frame, connect the cable to the terminal block (make sure the symbols F1, F2 match with the symbols on the outdoor unit), and fix the cable with a tie wrap.

- Power supply cable:** Route the cable through the frame and connect the cable to the terminal block (L, N, earth).




- a Circuit breaker
b Residual current device



- a Power supply and earth wiring
b Service cover with wiring diagram
c Transmission and user interface wiring

- Plastic clamp for tie wrap:** Pass tie wraps through the plastic clamps and fasten to fix the cables.

- Wrap the cables with the sealing material (accessory) to prevent water from entering the unit. Seal all gaps to prevent small animals from entering the system.




- a Small sealing (accessory)
b Wiring
c Plastic clamp for tie wrap

- Reattach the service cover.

Complete system example

1 user interface controls 1 indoor unit.



- a Outdoor unit
b Indoor unit
c User interface
d Most downstream indoor unit


NOTICE

Group control connection is NOT allowed.

15 Commissioning



CAUTION

- Each indoor unit has to be connected to a separate user interface. Only a safety system compatible remote controller can be used as the user interface. See technical data sheet for remote controller compatibility (e.g. BRC1H52/82*).
- The user interface has to be put in the same room as the indoor unit. For details, please refer to the installation and operation manual of the user interface.

15 Commissioning



NOTICE

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If NOT, burning of the compressor might be the result.

15.1 Checklist before commissioning

After the installation of the unit, first check the items listed below. Once all checks are fulfilled, the unit must be closed. Power-up the unit after it is closed.

☐	You read the complete installation and operation instructions, as described in the installer and user reference guide .
☐	The indoor unit is properly mounted.
☐	The outdoor unit is properly mounted.
☐	Make sure drain piping is properly installed, insulated and drainage flows smoothly. Check for water leaks. Possible consequence: Condensate water might drip.
☐	The ducting is properly installed and insulated.
☐	The refrigerant pipes (gas and liquid) are installed correctly and thermally insulated.
☐	There are NO refrigerant leaks .
☐	There are NO missing phases or reversed phases .
☐	The system is properly earthed and the earth terminals are tightened.
☐	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
☐	The power supply voltage matches the voltage on the identification label of the unit.
☐	There are NO loose connections or damaged electrical components in the switch box.
☐	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
☐	The stop valves (gas and liquid) on the outdoor unit are fully open.

15.2 To perform a test run



INFORMATION

- Perform the test run according to the instructions in the outdoor unit manual.
- The test run is only completed if there is no malfunction code displayed on the user interface or the outdoor unit 7-segment display.
- See the service manual for the complete list of error codes and a detailed troubleshooting guideline for each error.



NOTICE

Do NOT interrupt the test run.

16 Configuration

16.1 Field setting

Make the following field settings so that they correspond with the actual installation setup and with the needs of the user:

- Ceiling height
- Bottom suction or rear suction installation
- External static pressure setting using:
 - Airflow automatic adjustment setting
 - User interface
- Air volume when thermostat control is OFF
- Time to clean air filter
- Thermostat sensor selection
- Thermostat differential changeover (if remote sensor is used)
- Differential for automatic changeover
- Auto-restart after power failure

Setting: Ceiling height

This setting must correspond with the actual distance to the floor, capacity class and air flow directions.

If the distance to the floor is (m)	Then ⁽¹⁾		
	M	SW	—
≤2.7	13 (23)	0	01
2.7<x≤3.0			02
3.0<x≤3.5			03

Setting: Bottom suction or rear suction installation

This setting must correspond with the installation type: rear suction (default) or bottom suction.

If you have the installation with...	Then ⁽¹⁾		
	M	SW	—
Rear suction	13(23)	11	01
Bottom suction			02

⁽¹⁾ Field settings are defined as follows:

- M:** Mode number – **First number:** for group of units – **Number between brackets:** for individual unit
- SW:** Setting number
- :** Value number
- :** Default

Setting: External static pressure**INFORMATION**

- The fan speed of the indoor unit is preset to ensure the standard external static pressure.
- To set a higher or lower external static pressure, reset the initial setting with the user interface.

Settings for external static pressure can be achieved in 2 ways:

- Using the airflow automatic adjustment function
- Using the user interface

To set external static pressure by airflow automatic adjustment function**NOTICE**

- Do NOT adjust the dampers during the fan only operation for airflow automatic adjustment.
 - For the external static pressure higher than 100 Pa, do NOT use airflow automatic adjustment function.
 - If the ventilation paths have been changed, perform the airflow automatic adjustment again.
- Test run MUST be done with a dry coil, run the unit for 2 hours with fan only to dry the coil.
 - Check if the power supply wiring, duct, air filter are properly attached. If the closing damper is installed in the unit, make sure it is open.
 - If there is more than one air inlet and outlet, adjust the dampers so that the airflow rate of each air inlet and outlet is conform with the designed airflow rate.
- 1 Operate the unit in fan only mode prior to using the airflow automatic adjustment function.
 - 2 Stop the air conditioning unit.
 - 3 Set the value number "—" to 03 for **M** 11(21) and **SW** 7 and continue according to the following table:

Setting content:	Then ⁽¹⁾		
	M	SW	—
Airflow adjustment is OFF	11(21)	7	01
Press ON/OFF to return to normal operating mode.			03
Possible consequence: The operation lamp will light up and the unit will start the fan operation for airflow automatic adjustment.			
Operation stops after 1 to 8 minutes.			02
Possible consequence: Setting is finished and the operation lamp will be off.			

- 4 After airflow automatic adjustment is finished check if the value number "—" is set to 02. If there is no change, perform the setting again.

To set external static pressure by the user interface

Check the indoor unit setting: the value number "—" must be set to 01 for **M** 11(21) and **SW** 6.

- 1 Change the value number "—" according to the external static pressure of the duct to be connected as in table below.

External static pressure (Pa) ⁽¹⁾					
M	SW	—	Class		
			15~63	80+100	125+140
13(23)	6	01	30	40	50
		02	—	—	—
		03	30	—	—
		04	40	40	—
		05	50	50	50
		06	60	60	60
		07	70	70	70
		08	80	80	80
		09	90	90	90
		10	100	100	100
		11	110	110	110
		12	120	120	120
		13	130	130	130
		14	140	140	140
		15	150	150	150

Setting: Air volume when thermostat control is OFF

This setting must correspond with the needs of the user. It determines the fan speed of the indoor unit during thermostat OFF condition.

- 1 If you have set the fan to operate, set the air volume speed:

If you want...		Then ⁽¹⁾		
		M	SW	—
During thermostat OFF at cooling operation	LL ⁽²⁾	12 (22)	6	01
	Setup volume ⁽²⁾			02
	OFF ^(a)			03
	Monitoring 1 ⁽²⁾			04
	Monitoring 2 ⁽²⁾			05
During thermostat OFF at heating operation	LL ⁽²⁾	12 (22)	3	01
	Setup volume ⁽²⁾			02
	OFF ^(a)			03
	Monitoring 1 ⁽²⁾			04
	Monitoring 2 ⁽²⁾			05

^(a) Only use in combination with optional remote sensor or when setting **M** 10 (20), **SW** 2, — 3 is used.

Setting: Time to clean air filter

This setting must correspond with the air contamination in the room. It determines the interval at which "Time to clean filter" notification is displayed on the user interface.

⁽¹⁾ Field settings are defined as follows:

- **M**: Mode number – **First number**: for group of units – **Number between brackets**: for individual unit
- **SW**: Setting number
- —: Value number
- : Default

⁽²⁾ Fan speed:

- **LL**: Low fan speed (set during thermostat OFF)
- **L**: Low fan speed (set by the user interface)
- **Setup volume**: The fan speed corresponds to the speed the user has set (low, medium, high) using the fan speed button on the user interface.
- **Monitoring 1, 2**: The fan is OFF, but runs for a short time every 6 minutes to detect the room temperature by **LL** (Monitoring 1) or by **L** (Monitoring 2).

17 Technical data

If you want an interval of... (air contamination)	Then ⁽¹⁾		
	M	SW	—
±2500 h (light)	10 (20)	0	01
±1250 h (heavy)			02
Notification ON		3	01
Notification OFF			02

Setting: Thermostat sensor selection

This setting must correspond with how/if the remote controller thermostat sensor is used.

When the remote controller thermostat sensor is...	Then ⁽¹⁾		
	M	SW	—
Used in combination with indoor unit thermistor	10 (20)	2	01
Not used (indoor unit thermistor only)			02
Used exclusively			03

Setting: Thermostat differential changeover (if remote sensor is used)

If the system contains a remote sensor, set the increase/decrease increments.

If you want to change increments to...	Then ⁽¹⁾		
	M	SW	—
1°C	12 (22)	2	01
0.5°C			02

Setting: Differential for automatic changeover

Set temperature difference between cooling setpoint and heating setpoint in automatic mode (availability depends on the system type). Differential is cooling setpoint minus heating setpoint.

If you want to set...	Then ⁽¹⁾			Example
	M	SW	—	
0°C	12 (22)	4	01	cooling 24°C/heating 24°C
1°C			02	cooling 24°C/heating 23°C
2°C			03	cooling 24°C/heating 22°C
3°C			04	cooling 24°C/heating 21°C
4°C			05	cooling 24°C/heating 20°C
5°C			06	cooling 24°C/heating 19°C
6°C			07	cooling 24°C/heating 18°C
7°C			08	cooling 24°C/heating 17°C

Setting: Auto-restart after power failure

Depending on the needs of the user, you may disable/enable the automatic restart after a power failure.

If you want auto-restart after power failure...	Then ⁽¹⁾		
	M	SW	—
Disabled	12 (22)	5	01
Enabled			02

⁽¹⁾ Field settings are defined as follows:

- **M**: Mode number – **First number**: for group of units – **Number between brackets**: for individual unit
- **SW**: Setting number
- **—**: Value number
- **■**: Default

17 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

17.1 Wiring diagram

17.1.1 Unified wiring diagram legend

For applied parts and numbering, refer to the wiring diagram on the unit. Part numbering is by Arabic numbers in ascending order for each part and is represented in the overview below by "*" in the part code.



Symbol	Meaning	Symbol	Meaning
	Circuit breaker		Protective earth
	Connection		Protective earth (screw)
	Connector		Rectifier
	Earth		Relay connector
	Field wiring		Short-circuit connector
	Fuse		Terminal
	Indoor unit		Terminal strip
	Outdoor unit		Wire clamp
	Residual current device		


Symbol	Colour	Symbol	Colour
BLK	Black	ORG	Orange
BLU	Blue	PNK	Pink
BRN	Brown	PRP, PPL	Purple
GRN	Green	RED	Red
GRY	Grey	WHT	White
		YLW	Yellow

Symbol	Meaning
A*P	Printed circuit board
BS*	Pushbutton ON/OFF, operation switch
BZ, H*O	Buzzer
C*	Capacitor
AC*, CN*, E*, HA*, HE*, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R_*, NE	Connection, connector
D*, V*D	Diode
DB*	Diode bridge
DS*	DIP switch
E*H	Heater
FU*, F*U, (for characteristics, refer to PCB inside your unit)	Fuse

Symbol	Meaning
FG*	Connector (frame ground)
H*	Harness
H*P, LED*, V*L	Pilot lamp, light emitting diode
HAP	Light emitting diode (service monitor green)
HIGH VOLTAGE	High voltage
IES	Intelligent eye sensor
IPM*	Intelligent power module
K*R, KCR, KFR, KHuR, K*M	Magnetic relay
L	Live
L*	Coil
L*R	Reactor
M*	Stepper motor
M*C	Compressor motor
M*F	Fan motor
M*P	Drain pump motor
M*S	Swing motor
MR*, MRCW*, MRM*, MRN*	Magnetic relay
N	Neutral
n=*, N=*	Number of passes through ferrite core
PAM	Pulse-amplitude modulation
PCB*	Printed circuit board
PM*	Power module
PS	Switching power supply
PTC*	PTC thermistor
Q*	Insulated gate bipolar transistor (IGBT)
Q*C	Circuit breaker
Q*DI, KLM	Earth leak circuit breaker
Q*L	Overload protector
Q*M	Thermo switch
Q*R	Residual current device
R*	Resistor
R*T	Thermistor
RC	Receiver
S*C	Limit switch
S*L	Float switch
S*NG	Refrigerant leak detector
S*NPH	Pressure sensor (high)
S*NPL	Pressure sensor (low)
S*PH, HPS*	Pressure switch (high)
S*PL	Pressure switch (low)
S*T	Thermostat
S*RH	Humidity sensor
S*W, SW*	Operation switch
SA*, F1S	Surge arrester
SR*, WLU	Signal receiver
SS*	Selector switch
SHEET METAL	Terminal strip fixed plate
T*R	Transformer
TC, TRC	Transmitter
V*, R*V	Varistor

Symbol	Meaning
V*R	Diode bridge, Insulated-gate bipolar transistor (IGBT) power module
WRC	Wireless remote controller
X*	Terminal
X*M	Terminal strip (block)
Y*E	Electronic expansion valve coil
Y*R, Y*S	Reversing solenoid valve coil
Z*C	Ferrite core
ZF, Z*F	Noise filter





EAC



DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.

U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany, Czech Republic

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

Copyright 2020 Daikin

3P599602-1 2020.05